ISLAND CASE Cleaning Checklist

[] Allow the remainder of case to air dry

The Hill PHOENIX Learning Center



CAUTION

Do not perform these procedures until you have watched the Case Cleaning Guidelines video or until you have been properly trained by store personnel to clean the cases. Make sure you follow safety procedures outlined by your organization and abide by any state and local codes that may apply.

Pre-Cleaning Check List
[] Identify the cases that need to be cleaned (Note: Multiple cases usually run on the same refrigeration circuit, so plan
on cleaning all cases on that circuit at one time)
[] Post safety signs in the area of the cases that are going to be cleaned
[] Remove the product from the cases and relocate to refrigerated storage area
[] Turn off the refrigeration to the cases
[] Turn off the electrical circuits to the cases
[] Remove the deck pans and wire racks
[] Visually inspect the cases for debris and ice
[] Check the drain to make sure that it is not clogged
[] Gather all necessary cleaning materials
Island Cases
1. Clean the honeycomb assembly
[] To clean the honeycomb, use either a vacuum or use a soft-bristled brush and a spray bottle with warm, soapy
water or a mild cleaner
[] Spray with sanitizer and allow to air dry
2. Clean the shelves
[] Remove any product stops and set them aside temporarily
[] Clean the groove in the tag moulding with a mild cleaner or warm, soapy water and a small brush
[] Spray shelves with a mild cleaning solution and wipe them down with a clean cloth or paper towel
[] For lighted shelves, be sure that water does not enter the light channel. Never use a hose or submerge shelves in water
[] Spray shelves with sanitizer and allow them to air dry
[] Spray product stops with a mild cleaner or wash with warm, soapy water. They can also be cleaned in a
3-compartment sink.
Dry them with a clean paper towel or cloth
[] Spray product stops with sanitizer and allow to air dry
[] Replace product stops in the slotted tag moulding
[] replace product stops in the slotted tag moduling
3. Clean the tank
[] Lift fan plenum assembly
Do not spray cleaning solution or water directly on fans or electrical connections
[] Thoroughly spray tank with soap and hot water or a cleaning solution and let stand for 5 minutes
Scrub any heavily soiled areas with a non-abrasive cleaning pad
[] Rinse the case interior using warm to hot water
Apply sanitizer solution to the tank



4. Clean the exterior[] Spray the exterior panels with a mild cleaning solution and wipe them down with a clean cloth or paper towel
[] Spray the exterior panels with sanitizer and allow to air dry
Post Cleaning Check List
[] Make sure that the drain is free of debris that could have accumulated during cleaning
[] Clean up any spills on the floor
[] Make sure that all components have completely air dried
[] Turn on the electrical circuit and verify operation of electrical components
[] Turn on the refrigeration to the cases
[] Re-install the deck pans and wire racks

[] Once proper temperature is established in the cases, restock them according to the store plan-o-gram

